


HOW IT WORKS

RED-LIGHT SAFETY CAMERAS | DRIVER LIABILITY



The **1st Image** records the vehicle behind the violation point while the light is red.

The **2nd Image** records the vehicle proceeding through the intersection while the light is red.

The **3rd Image** records the driver of the vehicle.

*pole and equipment structure vary based on intersection design

- Step 1:** The system activates upon entering the intersection on a red light. The automated safety camera captures multiple images of an alleged violation from the rear and front of the vehicle.
- Step 2:** The first image shows the vehicle prior to entering the intersection while the light is red.
- Step 3:** The second image shows the vehicle proceeding through the intersection on a red light.
- Step 4:** The third image, taken by camera two, identifies the driver of the vehicle.
- Step 5:** A close-up image of the license plate is also provided with the evidence.
- Step 6:** Data, including the time, date, and duration of the yellow and red lights, is also recorded.
- Step 7:** Cameras also record a 12-second digital video of the violation, including six seconds prior to and six seconds after running the red light.

➤ END-TO-END RED-LIGHT SAFETY CAMERA SOLUTION



LET US HELP YOU FIND A SOLUTION
VerraMobility.com

CALL: (888) 776-8475

